

FISKARS®

HerbGarden™

User instructions



FISKARS®

HerbGarden™

User instructions

Contents

What is Fiskars HerbGarden™?	1
Fiskars HerbGarden™ Contents	2
Unpacking and installing	2
Basic functionality of your HerbGarden™	2
Accessories	3
Common herbs	3
Frequently Asked Question	4
Safety Instructions	4-5
Additional product information	5

Congratulations on your choice of the new Fiskars HerbGarden™

Enjoying a constant supply of fresh herbs is a simple growing pleasure thanks to the new Fiskars HerbGarden™ – a neat and simple indoor growing solution for people who enjoy cooking and the flavoursome benefits that herbs bring.

Fiskars HerbGarden™ is a practical and efficient growing solution to maintain store bought herbs and make them flourish.

Optimal conditions for growth

The optimized design of Fiskars HerbGarden™ not only ensures a continuous supply of your favorite herbs but it does so without the need for continuous maintenance. Simply place store-bought herbs (maximum four) directly to the Fiskars HerbGarden™. (Please note that special herb holders and capillary mats are available separately). Turn on the LED light unit and your herbs are free to grow bathed in optimal light conditions from top to bottom.

Continuous harvest

With no noisy pumps, a machine washable base and the simplest design, a continuous harvest of fresh herbs is yours to enjoy straight from your HerbGarden™ to your dinner table.

For more information:


www.fiskars.eu/urbangrowing



Fiskars HerbGarden™ Contents



Dishwasher-safe
Growing base



Transformer

LED-light core

3. Please ensure that the exterior surfaces of the growing base are dry and place it over the lamp such that the lamp sits in the middle of the unit.
4. Put the unit in a draft-free place away from direct heat or cold
5. Place herbs of your choice into the growing base.
6. Pour a requisite amount of water into the growing base up to the level of the indentations in the growing base taking care to avoid wetting the LED unit.

Now you are ready to grow herbs in your Fiskars HerbGarden™. Remember to add water regularly to ensure that your plants receive the hydration they need.



Unpacking and installing

1. Take the product from the package, place the lamp unit on a table or other flat surface. Rinse the growing base. If you wish, you can also wash the growing base in a dishwasher. Do not allow the light unit or transformer to come into contact with water or any other liquids.
2. Attach the transformer to a plug point and the jack point to the connection in the light unit.

Basic functionality of your HerbGarden™

Turn the light on and place the herbs in their own pots. The full spectrum white light immerses your herbs from top to bottom ensuring steady even growth.

Keep in mind that herbs need a night too, so it's recommended to switch the light off for approximately 8 hours a day.

Accessories

Fiskars Herb holders can be bought separately in addition to Fiskars capillary mats. Place store bought herbs into the holders with the capillary mat inbetween to ensure steady even hydration to the roots.



Typical herbs for growing in your HerbGarden™

Basil 💧💧💧

This sweet-smelling herb favorite thrives in Fiskars HerbGarden™. A traditional ingredient in Italian dishes, add at the last moment of cooking, to maintain the flavor.

Parsley 💧💧

One of the most popular, healthful and multi-purpose herbs. Parsley is widely used with fish and chicken or for use in risottos or in stews.

Chives 💧💧

With their bright green grassy-looking tops and delicate flavor, chives are the perfect alternative to onions in cooking.

Mint 💧💧💧

This vigorous herb works well in desserts and serves as a garnish in refreshing drinks.

Rosemary 💧

This woody aromatic herb is used in a variety of Mediterranean recipes from soups to breads. Rosemary is also an excellent herb for use with roasted meats.

Thyme 💧💧

Like mint, thyme is a bushy and vigorous herb, only with tiny leaves. Why not try it with potatoes or as part of a garnish?

Coriander 💧💧

This delicately scented and flavoured herb works beautifully with a variety of Asian dishes both in the cooking and as a decorative garnish.

💧 Light watering required

💧💧 Medium watering required

💧💧💧 Continuous watering required

Frequently Asked Questions

The light doesn't go on in my Fiskars HerbGarden™

Please check that the transformer is plugged in and the corresponding jack point is attached to the light unit. If the power source is connected correctly and there is still no light, please return the unit to the dealer from whom you purchased it.

How much water should I put in the unit?

Water should never exceed the indentations in the base of the herb holder (approximately 2 cm). Also take care to add water carefully avoiding the LED core, especially at the top of the unit.

I have a number of herbs in the HerbGarden™ - some are flourishing, others are not. What could be the reason for that?

There could be any number of reasons – from the quality of the herbs you purchased, overtrimming, to the level of water. Some herbs require more water like basil and some less. Check the website for more details on the most common herbs and their preferences. For herbs using less water, use a capillary mat in a herb holder (items sold separately).

What is the purpose of the capillary mats?

The capillary mats (available as accessories along with the herb pot) serve to deliver a constant and even supply of water without waterlogging the roots of the herb – this suits some herbs better than others. Simply place the capillary mat in the base of the orange herb holder and ensure that the mat touches to the water below.

Can I grow herbs from seed in my Fiskars HerbGarden™

In principle, yes you can. Although Fiskars HerbGarden™ has been primarily designed to maintain and promote the growth of store-bought herbs, the light it provides is optimal for the growth of all plants and seeds. By all means experiment!

Safety Instructions

Important!

Read these instructions carefully before use. Take all warnings into consideration and keep the instructions for later consultation.

The manufacturer is not responsible for any damage resulting from misuse or use of the product in conflict with the instructions and/or its intended purpose.

In unclear situations, please contact a retailer or the Fiskars customer service*

Installation

WARNING! Risk of electric shock or fire.

For indoor use only. Children must only use the device under parental supervision.

Place the product in a safe place so that it does not fall and break or cause injury.

Only use the product for its intended purpose. The product is not intended for professional use.

Only use the power grid connector provided with the product. Only connect the device to the power source listed in the instructions (AC 100–240 V).

Do not use the product near water, including dripping or splashing water sources (such as a shower or indoor fountains). Exposing the lamp area to water, rain, liquid or moisture can cause a risk of electric shock or fire.

Do not cover the product and remember to leave at least 15 cm of space around the device to ensure sufficient airflow.

Use

Take special care and follow the instruction manual when adding water to the growing base. Do not allow the electronic parts of the product to come into contact with liquids.

Under no circumstances modify the power cable or plug of the product. If the plug does not fit the power socket, ask an electrician to make the required modifications. Protect the power cable

so it is not stepped on or placed under pressure, especially around the plug, socket and charger or the connection point leading to the device.

Detach the device from the power source during a thunderstorm or when it is out of use for a prolonged period of time.

Maintenance

Please contact Fiskars customer service if the product malfunctions, if, for example, the power cable or plug is damaged, the lamp area or remote control is exposed to water, rain, liquid or moisture, or if the product has been dropped or foreign objects have been inserted into it.

Follow the cleaning instructions in the user manual. Separate the growing base from the lamp before cleaning the device. Clean the lamp using only a dry towel (no liquids, abrasive substances or solvents).

Disposing of electric and electronic products.

The CE guarantee and further information on the product are available at www.fiskars.eu/urbangrowing

Additional product information

Spare parts including Fiskars Herb holders and capillary mats are available through

*Fiskars customer service.

FINLAND: +358 20 4396 300
(Mon. – Fri.: 10:00 – 15:00)
kuluttajapalvelu.suomi@fiskars.com.

DENMARK: +45 87 2011 00
(Mon. – Thu.: 8:00 – 16:00/ Fri.: 8:00 – 15:30)
fiskarsdk@fiskars.com

GERMANY: +49 52 2193 5299
(Mon. – Thu.: 08:00 – 15:00, Fri.: 08:00 – 12:00)
info.garten@fiskars.com

FRANCE: +33 1 69 75 15 35
(Mon., Tues. and Thur.: 9:00 – 17:00. Weds.: 9:00 – 12:30)
serviceconsommateurs.jardin@fiskars.com

- **Light unit**
- **Growing base**
- **Transformer**

Owing to the constant development of our product range, we reserve the right to change the products without preceding notice. We take no responsibility for printing errors.

Manufacturer:
Fiskars Garden Oy Ab
10330 Billnäs, FINLAND

Design

Material: **ABS**

Colour: **White**

Product dimensions and weight

Height: **110 mm**

Length: **368 mm**

Width: **227 mm**

Net weight: **1100 g**

Technical information

Power:
input: **AC 100–240 V / 50-60 Hz / 0.5 A**
Output: **DC 12 V / 1500 mA**

Use only AC/DC transformer **HNP18-120**
made by HN power Germany

Lamp technology: **5 LED unit**

Maximum power of provided lamp: **9 W**

Light angle coverage: **360°**

Fiskars is not liable for any damage caused by inappropriate use. Please refer to the user manual. More information available www.fiskars.eu/herbgarden

Fiskars HerbGarden™

Extends the life of your herbs at home



FISKARS®

the touch of orange